



Wyoming Water Resources Center  
University of Wyoming

Dennis Kaan, Wyoming Water Resources Center and Joe Hiller, Department of Range Management

## Groundwater Contamination

Groundwater supplies over 54 percent of the population of Wyoming with domestic water. Over 90 percent of rural domestic water comes from groundwater as well. Because groundwater is such an important resource, it needs to be protected from the types and levels of contamination that could have detrimental effects on humans and the environment. Not all contaminants are bad, and they can be natural and/or human-made. Once groundwater is contaminated, clean up is a very difficult and expensive process.

Many people believe the soil above groundwater aquifers will filter contaminants out of recharge water, but this is not usually true. The ability of soils to filter contaminants depends on many variables including, the chemical properties of contaminants, soil, subsoil and geologic properties, site conditions and climatic factors. These variables combined with the depth to the water table (top of an aquifer) make groundwater contamination a very site-specific problem.

### How Groundwater Moves

Water is often referred to as the universal solvent. It will dissolve many natural and synthetic chemical compounds. Water flowing through the soil dissolves materials from soil and rock, and chemicals from various land use activities. How quickly a particular contaminant reaches a groundwater aquifer depends on the properties of the contaminant and the soil, and on other site conditions.

Soil Properties that can influence its ability to filter out or retain contaminants are texture, permeability, and organic matter content. Texture refers to the relative proportion of sand, silt, and clay contained in the soil. Permeability is a measure of how fast water moves through the soil. Coarse-textured sandy soil allows rapid water movement through the soil and is less capable of filtering out some contaminants than fine-textured clay soils. These highly permeable soils will permit contaminants to leach more quickly than less permeable soils. Leaching of a contaminant is the downward movement of a dissolved or suspended substance by water. The amount of organic matter also determines the capacity of soil to hold water and absorb chemicals. Generally, the greater the amount of organic matter in soil, the greater the capacity of the soil to absorb chemicals and reduce leaching.

Chemical Properties influencing a contaminant's ability to reach groundwater aquifers are solubility, adsorption, volatility, and degradation. Solubility is how readily a chemical dissolves in water. Water-soluble chemicals are easily leached. Adsorption is the ability of a chemical to be held on the surface of soil particles or organic matter. A chemical that is held tightly to soil particles is less likely to be leached. Volatility is the ability of a chemical to be lost to the atmosphere. A highly volatile chemical may be lost to the atmosphere before being leached downward. Degradation is the

breakdown or alteration of a substance in soil or water. A contaminant which degrades slowly is more likely to be susceptible to leaching.

Site Conditions such as depth to the groundwater are important with respect to contamination. Less distance between the soil surface and water table generally increases the chance for leached contaminants to reach an aquifer. There is less time for contaminant adsorption and degradation to occur. Slope on a site can affect the likelihood of contamination as well. A steep slope may create more runoff, which may transport a contaminant to a different location. Excessive rainfall increases percolation, leaching, and runoff. Cold soil temperatures slow the rate of degradation, allowing a chemical to be leached over a longer period of time.

Contaminants in an aquifer do not mix uniformly, rather remaining in a plume (or concentration) in the aquifer. This plume then moves slowly through an aquifer along with groundwater movement. Contaminants position themselves differently in an aquifer according to their weight relative to water. Lighter materials, such as gasoline, will float at or near the top of an aquifer. Materials such as minerals will dissolve in water and heavier, insoluble materials such as chlorinated hydrocarbons will settle to the bottom of an aquifer. Knowledge of these properties can be beneficial because some contaminants may remain localized, allowing for better detection and cleanup.

## Causes of Groundwater Contamination

Virtually all uses of water degrade its quality. Quality is a relative term related to a specific intended use. Land uses or activities on the surface can contribute to groundwater contamination. These uses or activities include landfills, underground storage tanks, sludge disposal, septic systems, agriculture, and industry. The type of contaminants released by these activities include bacteria, nitrates, volatile organics, hydrocarbons, pesticides, metals, and minerals. Groundwater contaminants may also be naturally occurring substances such as fluorides, selenium, and radionuclides. By identifying the type of activity, particularly those upgradient from a water supply, it may be possible to determine types of contaminants having the potential to reach groundwater supplies.

Landfills may contribute any of the above named contaminants to groundwater. Evidence indicating contamination includes observed leachate runoff, seepage into nearby surface water, and high levels of the contaminants in well water or soil tests. Contaminants may be released if: the cover or liner of a landfill leaks or, if there is leachate movement without adequate control or the landfill is on highly permeable soils.

Underground Storage Tanks if leaking, can introduce contaminants into groundwater quite easily because the tank is below the surface, and contaminants are generally not subject to volatilization. Indications of leaking tanks include odors in water or nearby basements, tank inventory losses, and spills. Tanks can leak because of corrosion, poor installation or maintenance, lack of a backup containment, or deterioration of abandoned tanks.

Sludge Disposal can introduce bacteria, nitrates, volatile organics, hydrocarbons, pesticides, metals, or minerals into groundwater. Groundwater can be contaminated by sludge disposal because of improper application methods, because of the nature of the sludge, or of the underlying soils and subsoils as well as surface hydrologic features.

Septic Systems can introduce the same types of contaminants into groundwater as sludge disposal. Evidence of contamination includes waste water seeping above ground or high contaminant levels in water or deep soil tests. Causes of groundwater contamination by a septic system include faulty installation and/or maintenance, disposal of certain household chemicals into the system, overloading the capacity of a system, or septic tank cleaning additives.

Agricultural practices can introduce nitrates, petroleum products and pesticides into groundwater. Water tests can detect these types of contamination in groundwater. Groundwater contamination from agriculture can be caused by improper or ill-timed application of agricultural chemicals and spills.

Industry can introduce contaminants such as volatile organics, hydrocarbons, pesticides, metals, or minerals into groundwater. Groundwater contamination is detected by water tests. Some causes of contamination include leaks and improper storage and handling at industrial sites, spills from transport accidents, and broken pipelines.

## Detection of Groundwater Contamination

The best method of detecting groundwater contamination is a water test for a particular contaminant. No single test can detect all of the contaminants discussed here. Water tests should be specific for the intended purpose of the water source. If you are supplied by a municipal water system, water testing is done for you, in accordance with applicable state and federal laws. A private water source is different, however. It is your responsibility to protect yourself by knowing the quality of your private well water.

If you detect changes in your water, you may have a contamination problem. To locate the source of the problem use common sense. Look for clues to the source of the contamination, then have your water tested to determine the types and concentrations of contaminants. Contact your local public health department or the University of Wyoming Cooperative Extension Service office in your county for information on proper methods for collecting water samples, where to send the sample, what potential contaminants to be tested, how to interpret the results and what to do if there is a problem with your water.

## Protecting Groundwater Quality

Prevention is the key to maintaining good quality groundwater. Individuals make the difference. There are some basics we can all practice to protect our groundwater quality:

- Use, store, and dispose of household, shop, lawn and garden, and auto care products according to label instructions.
- Use, store, and dispose of agricultural chemicals according to recommendations, and/or label instructions, and use Integrated Pest Management (IPM) practices where appropriate.
- Test underground storage tanks and pipelines regularly to detect possible leaks.
- Follow regulations and guidelines for installing, plugging, and abandoning any type of well.
- Manage domestic septic tanks and disposal fields to prolong life and maximize their ability to remove contaminants.
- Contact federal, state, and local agencies for applicable rules, regulation, and guidance on groundwater protection.

## References

- ACRE Fact Sheet No. 8. Glossary of Water Quality Protection Terms. Kansas City, MO 64179-0386.
- University of Wyoming Cooperative Extension Service, Water Resources Center. 1990. Water Sense Wheel.
- Homsby, A.G. 1990. Groundwater and Public Policy, Series #2: How Contaminants Reach Groundwater.
- Cooperative Extension, University of Connecticut. Land Use and Well Water Contamination. Water Quality Fact Sheet #1.
- Mora, K.L., L.R. Larson and S.J. Rucker, IV. 1986. Wyoming Groundwater Quality. US Geological Survey Water Supply Paper 2325.
- Ostresh, L.M., R.A. Marston and W.M. Hudson. 1990. Wyoming Water Atlas. Wyoming Water Development Commission and University of Wyoming, Laramie.
- Powell, G.M. 1989. Groundwater and Well Contamination. Cooperative Extension Service, Kansas State University. MF-932.
- Raymond, L.S. 1988. Groundwater Contamination. Bulletin no. 2, New York State Water Resources Institute.
- US Environmental Protection Agency. 1990. The Safe Drinking Water Act. US Government Printing Office. 1991-788-645.
- US Department of Agriculture. 1991. Focus on Water: Drinking Water. Extension Service Water Quality Initiative Bulletin.
- Vandre, W. 1990. How Groundwater Contamination Occurs. Cooperative Extension Service, University of Alaska. 100G-00545.
- Zimmerman, E.A. 1987. Wyoming Groundwater Resources. US Geological Survey Water-Supply Paper 2275.

---

*Issued in furtherance of Cooperative Extension work, Acts of May 8 and June 30, 1914, in cooperation with the U.S. Department of Agriculture, Jim DeBree, Director, Cooperative Extension Service, University of Wyoming, Laramie, WY 82071. Persons seeking admission, employment, or access to programs of the University of Wyoming shall be considered without regard to race, color, national origin, sex, age, political belief, handicap, or veteran status. Development of this publication was funded in part by a U.S. Environmental Protection Agency nonpoint source program grant from the Wyoming Department of Environmental Quality, Water Quality Division. The views expressed in this publication do not necessarily reflect those of the USEPA or Wyoming DEQ.*